


### Accessories

**Battery holder** Powered by Makita Li-ion Battery



As a charger for smart phones



Part No. YL00000004

### Jacket Size



	size (in cm)	S	M	L	XL	2XL	3XL
DCJ205 /	Length	26-3/4"	27-1/8"	28"	29-1/2"	30-3/4"	32-1/4"
	Shoulder	19-7/8"	20-5/8"	21-1/2"	21-7/8"	22-1/4"	22-5/8"
DCJ206 /	Sleeve	24-7/8"	25-3/8"	26"	26-3/8"	26-3/4"	27-1/8"
	Chest	42-1/2"	46-1/2"	50-3/8"	54-3/8"	57-1/2"	61-3/8"
	Waist	40"	44"	48"	52"	55"	59"
DCV202 /	Length	28-3/8"	28-3/4"	29-1/8"	29-1/2"	30"	30-5/16"
	Shoulder	18-3/4"	19-1/2"	20-1/4"	21"	21-7/8"	22-5/8"
	Chest	44-7/8"	47-1/4"	49-5/8"	52"	54-3/8"	56-11/16"
	Waist	45-5/8"	48"	50-3/8"	52-3/4"	55-1/8"	57-1/2"

### Longer continuous run time on a single full battery charge

Model No.	Battery holder	Li-ion Battery		Continuous run time Low / Medium / High	Net weight Jacket size L	Pockets
DCJ205			6.0Ah BL1860B	35 / 14 / 8.5 h with BL1860B	1.1kg (2.5 lbs.)	5
DCJ206			5.0Ah BL1850B		1.2kg (2.5 lbs.)	
DCV202			4.0Ah BL1840B 3.0Ah BL1830B 1.5Ah BL1815N	35 / 20 / 10 h with BL1860B	0.5kg (1.1 lbs.)	4

When QUALITY & SERVICE COUNTS – Choose Makita

makita.ca



## Cordless Heated Jacket Series DCJ205 / DCJ206 / DVC202



# HEATED JACKET and VEST






# HEATED JACKET and VEST




Max run time  
**7.0 h**  
Mode : High  
Battery : BL1850B

## Heating effects

When wearing in a minus 5 degree C environment (in High mode)




when switch is off



about 15 minutes after switch-on

## 3 Heat settings

Continuous runtime on a single full battery charge



Low	Medium	High
29h	11h	7h

with BL1850 (18V-5.0Ah Battery)

## 5 Heat zones

Left chest, right chest and back have each heating element.



## 4 Heat zones

Left chest, right chest and back, neck have each heating element.



## Wind and Water Resistance

prevents penetration of water such as light rain.



**Fleece lining**  
warms a body even when switch is off



**Jacket type**  
DCJ205



**High-visibility type**  
DCJ206



**Vest type**  
DCV202

## Washable and dryable

Detach the battery holder from the jacket or vest before washing.



## Features



Battery pocket  
■ DCJ205  
■ DCJ206  
■ DCV202



Two-way zip fastener  
■ DCJ205  
■ DCJ206  
■ DCV202



Pen pocket  
■ DCJ205



Detachable hood  
■ DCJ206



Name tag holder  
■ DCJ206



Retroreflective material  
■ DCJ206