



Item No.	Type	Sub	Part No.	Description	Qty	Unit
001			GM00001269	SCREW 3X12PB(B0130120202)	4	PC.
002			GM00002324	REAR CASE	1	PC.
003			GM00001267	SCREW 2.6X8PWB(B0126080006)	2	PC.
004			GM00002349	LED ASSY	1	PC.
005			GM00002322	LENS	1	PC.
006			GM00002321	FRONT CASE	1	PC.
007			GM00002325	LEFT ROTATOR	1	PC.
008			GM00001270	SPRING (B1214801020)	1	PC.
009			GM00001279	SPRING LID (C1020801001)	1	PC.
010			GM00002326	LEFT ROTATOR BRACKET	1	PC.
011			GM00001282	FIX PLATE (C3020801001)	1	PC.
012			GM00002327	RIGHT ROTATOR BRACKET	1	PC.
013			GM00001279	SPRING LID (C1020801001)	1	PC.
014			GM00001270	SPRING (B1214801020)	1	PC.
015			GM00002328	RIGHT ROTATOR	1	PC.
016			GM00001268	SCREW 2.6X10KA(B0126100121)	3	PC.
017			GM00001268	SCREW 2.6X10KA(B0126100121)	3	PC.
018			GM00001269	SCREW 3X12PB(B0130120202)	2	PC.
019			GM00001269	SCREW 3X12PB(B0130120202)	8	PC.
020			GM00002336	HOUSING ASSY	1	SET
021			GM00002331	HANGING HOOK ASSY	1	PC.
022			GM00002330	HOOK COVER ASSY	1	PC.
022		INC.		Item No. 23-26		
023			GM00002339	LOCKING SHAFT	1	PC.
024			GM00002340	SPRING	1	PC.
025			GM00002341	COVER	1	PC.
026			GM00001322	SCREW 2.6X8 PB	1	PC.
027			GM00001322	SCREW 2.6X8 PB	3	PC.
028			GM00001322	SCREW 2.6X8 PB	2	PC.
029			GM00002332	HOOK SUPPORT	1	PC.
031			GM00002249	SWITCH SPRING	1	PC.
032			GM00002333	SWITCH ASSY	1	PC.
033			GM00002337	MAIN PCBA ASSY	1	PC.
034			GM00002231	STRAP HOOK	1	PC.
035			GM00002338	TERMINAL ASSY	1	PC.
ACCESSORIES				- Visit www.makita.ca for more accessories information -		
A01			GM00001288	SHOULDER HOOK SET G0180100100	1	PC.
A02			GM00001326	LAMP SHADE	1	PC.
A03			450128-8	BATTERY COVER	1	PC.
A04			----	BATTERY CHARGER	1	PC.
A05			----	18V LI-ION BATTERY	1	PC.