



Item No.	Type	Sub	Part No.	Description	Qty	Unit
001			GM00002458	LENS	1	PC.
002			GM00002459	USB SWITCH BUTTON	1	PC.
003			GM00002460	STRAP HOOK	1	PC.
004			GM00002461	USB COVER	1	PC.
005			GM00002462	LED PCBA ASSY	1	PC.
006			GM00002463	USB PCBA ASSY	1	PC.
007			GM00002464	BATTERY HOLDER ASSY	1	PC.
008			GM00002465	MAIN PCBA ASSY	1	PC.
009			GM00002497	BODY ASSY BLUE	1	PC.
		INC.		Item No. 10		
010			GM00002496	XGT LABEL	1	PC.
011			GM00002468	SWITCH SPRING	1	PC.
012			GM00002469	SWITCH SPRING BRACKET	1	PC.
013			GM00002470	SWITCH ASSY	1	PC.
014			GM00001012	SCREW 3X12 PB BLACK ZN	3	PC.
<u>ACCESSORIES</u>			- Visit www.makita.ca for more accessories information -			
A01			GM00002457	LAMP SHADE	1	PC.
A02			-----	40V MAX LI-ION BATTERY		
A03			-----	BATTERY CHARGER		