



<b>Item No.</b>	<b>Type</b>	<b>Sub</b>	<b>Part No.</b>	<b>Description</b>	<b>Qty</b>	<b>Unit</b>
001			GM00002477	LENS	1	PC.
002			GM00002459	USB SWITCH BUTTON	1	PC.
003			GM00002478	STRAP HOOK	1	PC.
004			GM00002479	USB COVER	1	PC.
005			GM00002480	LED PCBA ASSY	1	PC.
006			GM00002481	MAIN PCBA ASSY	1	PC.
007	2		GM00002498	BODY ASSY BLUE	1	PC.
008			GM00002468	SWITCH SPRING	1	PC.
009			GM00002484	SWITCH SPRING BRACKET	1	PC.
010			GM00002485	SWITCH ASSY	1	PC.
011			GM00002486	SCREW 2.6X12 PB BLACK ZN	3	PC.

**ACCESSORIES**

**- Visit [www.makita.ca](http://www.makita.ca) for more accessories information -**

A01			GM00002476	LAMP SHADE	1	PC.
A02			-----	12V CXT SLIDE TYPE LI-ION BATTERY		
A03			-----	BATTERY CHARGER		