



Item No.	Part No.	Description	Q'ty	Unit
1	265769-5	WING BOLT M5X15	2	PC.
2	345500-6	SUPPORT	2	PC.
3	252189-2	HEX.NUT M5	7	PC.
4	345501-4	STOPPER PLATE	2	PC.
5	265152-6	PAN HEAD SCREW M5X20	7	PC.
6	418846-4	CAP	4	PC.
7	165401-0	OUTER FRAME	1	PC.
8	154543-5	INNER FRAME COMPLETE	1	PC.
9	252191-5	HEX.LOCK NUT M10-17	2	PC.
10	257744-5	SLEEVE 10	2	PC.
11	267796-8	PLAIN WASHER 10	4	PC.
12	265525-3	HEX.BOLT M10X75	2	PC.
13	819173-6	MAKITA LOGO LABEL	1	PC.
14	345496-1	FIX PLATE	3	PC.
15	418847-2	FOOT	3	PC.
16	252651-7	NUT M12	1	PC.
17	266353-9	ADJUST BOLT M12	1	PC.
18	257947-1	STOP RING E-10	4	PC.
19	324531-8	SLEEVE 7	4	PC.
20	265527-9	HEX.BOLT M6X45	4	PC.
21	267795-0	PLAIN WASHER 6	4	PC.
22	252190-7	HEX.LOCK NUT M6-10	4	PC.
23	163452-7	LOCK PLATE COMPLETE	2	PC.
30	265769-5	WING BOLT M5X15	2	PC.
31	345502-2	SUPPORT PLATE	1	PC.
32	252188-4	HEX.NUT M8	4	PC.
33	265526-1	HEX.BOLT M8X55	4	PC.
34	781217-1	WRENCH 10-13	2	PC.
C01	847050-2	CARTON	1	PC.

*Item No. 1 - 23 ... Stand Assembly (Part No. N/A)

*Item No. 30-34 ... Diagram not available

**For Model: Makita Mitre Saw (LS1440, LS1221, LS1040, LS1013, LS1013L
LS1212, LS1214, LS1214L, LS1016, LS1016L, LS1216, LS1216L, 2012NB, LXSL01Z, DLS713Z)**