




10 - 2014  
DC18RD  
DUAL (2-PORT) RAPID CHARGER



Item No.	Type	Ref	Part No.	Description	Qty	Unit
001			804Y51-3	INDICATION LABEL	1	PC.
002			804Y52-1	MAKITA LOGO LABEL	1	PC.
003			455546-5	TERMINAL COVER, BLUE	2	PC.
004			231474-6	COMPRESSION SPRING 4	4	PC.
005			142845-1	CHARGER CASE COMPLETE	1	PC.
		INC.		Item No. 6,7		
006			455402-9	LENS B	1	PC.
007			455401-1	LENS A	1	PC.
008			804Y47-4	CHARGING CONDITION LABEL	1	PC.
009			266278-7	TAPPING SCREW FLANGE BT3X10	2	PC.
010			632E11-3	TERMINAL UNIT	2	PC.
011			638499-5	SCIROCCO FAN	2	PC.
012			266764-8	TAPPING SCREW 3X8	4	PC.
013			233194-8	COMPRESSION SPRING 4	2	PC.
014			455399-2	TERMINAL BASE	2	PC.
015			620203-6	CHARGING CIRCUIT	2	PC.
		INC.		Item No. 16,17		
016			652802-6	FUSE	1	PC.
017			647321-5	VARISTOR	1	PC.
018	2		667982-5	CORD W/PLUG 2P-18-2.0M	1	PC.
019			620325-2	FILTER CIRCUIT	1	PC.
020			620412-7	* USB CIRCUIT (removed)	1	PC.
021			455398-4	CHARGER CASE COVER	1	PC.
022	1		455403-7	* USB COVER	1	PC.
	2		412817-3	* COVER	1	PC.
023			286255-3	CAP 13	4	PC.
024			266426-8	TAPPING SCREW 4X20	6	PC.
025			850E35-9	DC18RD NAME PLATE	1	PC.
E01			804Y49-0	CAUTION LABEL	1	PC.
E02			810K34-9	CAUTION LABEL	1	PC.
C01			877474-8	CARTON F/DC18RD	1	PC.

### SERVICE CHANGES

#### 1. Changes on USB Cover

(T/#DF488)

Item No.	Description	Type 1	Type 2
20	USB CIRCUIT	620412-7	-----
22	USB COVER	455403-7	412817-3

Above parts are completely interchangeable as a set.