



DTW301XV

PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		266130-9	TAPPING SCREW BIND PT 3X16	8	PC.
002	2	191K95-1	HOUSING SET	1	SET
002	2	INC. 263005-3	RUBBER PIN 6	2	PC.
002	2	INC. 252126-6	HEX. LOCK NUT M4-7	2	PC.
002	2	INC. 8012S7-2	CAUTION LABEL	1	PC.
003		268284-8	PIN 1.5	1	PC.
004		263036-2	RUBBER PIN 5	1	PC.
005		857P43-7	DTW301XV NAME PLATE	1	PC.
006		422584-2	BUMPER	1	PC.
007		412556-5	HAMMER CASE COVER	1	PC.
008	1	140T36-8	HAMMER CASE COMPLETE	1	PC.
008	2	1410F7-0	HAMMER CASE COMPLETE	1	PC.
009		265472-8	HEX. SOCKET HEAD BOLT M4X25	4	PC.
010		261154-0	NYLON WASHER 28	1	PC.
011		322045-1	CLIP	1	PC.
012		323675-1	PIN 4	1	PC.
013		136240-5	ANVIL A ASSY	1	PC.
013	INC.		Item No. 11,12		
014		327572-3	HAMMER	1	PC.
015		216001-0	STEEL BALL 3.5	24	PC.
016		267175-0	FLAT WASHER 24	1	PC.
017		232615-7	COMPRESSION SPRING 25	1	PC.
018		216011-7	STEEL BALL 5.6	2	PC.
019		227338-0	SPUR GEAR 22	3	PC.
020		327573-1	SPINDLE	1	PC.
021		268311-1	PIN 5	3	PC.
022		233910-8	RING SPRING 43	1	PC.
023		227337-2	INTERNAL GEAR 51	1	PC.
024		213785-1	O-RING 49	1	PC.
025		140T38-4	INTERNAL GEAR CASE COMPLETE	1	PC.
026		266490-9	TAPPING SCREW PT 2X6	3	PC.
027		652069-6	FLAT HEAD SCREW M3X6	3	PC.
028		620C65-0	CONTROLLER	1	PC.
029	1	629477-6	STATOR	1	PC.
029	2	629A98-0	STATOR	1	PC.
030		619626-3	ROTOR	1	PC.
031		412691-9	REAR COVER	1	PC.
032		266130-9	TAPPING SCREW BIND PT 3X16	2	PC.

Item No	Type	Part No	Description	Qty	Unit
033		620521-2	LED CIRCUIT	1	PC.
034		455053-8	F/R CHANGE LEVER	1	PC.
035		651443-5	SWITCH C3JR-4B	1	PC.
036		643874-2	TERMINAL	1	PC.
037		140V37-8	SWITCH PLATE COMPLETE	1	PC.
037	INC.	8012S9-8	SWITCH LABEL	1	PC.
039		424517-3	CUSHION	1	PC.
041		857P44-5	DTW301XV SERIAL NO. LABEL	1	PC.
042		632R73-9	LEAD UNIT	1	PC.
100		266622-8	+ TRUSS HEAD SCREW M4X12	1	PC.
A02		346449-3	HOOK	1	PC.
A03		824979-9	PLASTIC CARRYING CASE	1	PC.
A03	INC.	162302-3	LATCH	2	PC.
A07		----	BATTERY CHARGER		
A08		450128-8	BATTERY COVER	1	PC.
A09		----	18V LI-ION BATTERY	1	PC.