

PARTS LIST

Item No	Type	Part No	Description	Qty	Unit	
001		162494-8	FLANGE NUT COMPLETE	1	PC.	
002		412638-3	NUT COVER	1	PC.	
003		136373-6	SPROCKET COVER ASSY	1	PC.	
003	INC.		Item No. 1,2,4-6			
004		347707-0	GUIDE PLATE L	1	PC.	
005		265954-0	TAPPING SCREW BIND PT3X8	1	PC.	
006		422599-9	CHIP GUIDE	1	PC.	
007		266905-6	H.L. SOCKET HEAD BOLT M5X12	1	PC.	
008		347708-8	GUIDE PLATE R	1	PC.	
009		911128-8	P.H.SCREW M4X16 WITH WR	2	PC.	
010		183R95-7	GEAR CASE HOUSING SET	1	SET	
010	INC.	8026G0-9	CAUTION LABEL	1	PC.	
011		252291-1	HEX. NUT M6	1	PC.	
012		232626-2	CORNED DISK SPRING 14	2	PC.	
013		347705-4	LOCK WASHER 12	1	PC.	
014		226992-7	SPROCKET 6	1	PC.	
015		347705-4	LOCK WASHER 12	1	PC.	
016	2	140V32-8	SPINDLE COMPLETE	1	PC.	
017		422602-6	GROMET	1	PC.	
018		227620-7	DRIVE GEAR	1	PC.	
019		227634-6	STRAIGHT BEVEL GEAR 14	1	PC.	
020		347706-2	TENSION SLIDE	1	PC.	
021		327606-2	ADJUST SCREW	1	PC.	
022		227496-2	STRAIGHT BEVEL GEAR 14	1	PC.	
023		126832-8	TANK CAP ASSEMBLY	1	PC.	
023	1	INC.	213894-6	O-RING 25	1	PC.
023	2	INC.	213A11-4	O-RING 25	1	PC.
024	1		136372-8 * OIL TANK ASSEMBLY	1	PC.	
024	1	INC.		Item No. 23,39-41		
024	2		137016-3 * OIL TANK ASSEMBLY	1	PC.	
024	2	INC.		Item No. 23,39-41		
025		266326-2	TAPPING SCREW 4X18	3	PC.	
026	1		136301-1 * GEAR CASE ASSEMBLY	1	PC.	
026	1	INC.	213437-4	O RING 28	1	PC.
026	2		137017-1 * GEAR CASE ASSEMBLY	1	PC.	
026	2	INC.	213437-4	O RING 28	1	PC.
027	2		226995-1	SPIRAL BEVEL GEAR 18	1	PC.
028		211131-2	BALL BEARING 6001DDW	1	PC.	

Item No	Type	Part No	Description	Qty	Unit
029		211148-5	BALL BEARING 6001ZZ	1	PC.
030		961052-5	RETAINING RING S-12	1	PC.
031		962106-1	RETAINING RING R-28	1	PC.
032		211491-2	BALL BEARING 609DDW	1	PC.
033		961005-4	RETAINING RING S-9	1	PC.
034		226884-0	WORM GEAR	1	PC.
035		961011-9	STOP RING E-4	1	PC.
036		422600-0	OIL TUBE 3-70	1	PC.
037	1	140U04-7	OIL PUMP COMPLETE	1	PC.
037	2	141N25-0	OIL PUMP COMPLETE	1	PC.
038		911128-8	P.H.SCREW M4X16 WITH WR	1	PC.
039		452666-6	NIPPLE	1	PC.
040		231975-4	SPRING	1	PC.
041		422601-8	OIL TUBE 3-14	1	PC.
043		266326-2	TAPPING SCREW 4X18	3	PC.
044		922243-3	HEX. SOCKET HEAD BOLT M5X25	1	PC.
046		922202-7	HEX. SOCKET HEAD BOLT M5X8	1	PC.
047		183P85-8	GRIP SET	1	SET
047	INC.	931202-6	HEX. NUT M5	1	PC.
048		140V21-3	SWITCH CIRCUIT COMPLETE	1	PC.
048	INC.	819S81-5	SWITCH LABEL	1	PC.
049		459758-2	SWITCH LEVER	1	PC.
050		233622-3	TORSION SPRING 12	1	PC.
051		651438-8	SWITCH C3JW-6B-PAN	1	PC.
052		632G61-0	SWITCH UNIT	1	PC.
053		459759-0	LOCK OFF LEVER	1	PC.
054		233101-1	COMPRESSION SPRING 4	1	PC.
057		922233-6	H.S.H.BOLT M5X20 WITH WR	1	PC.
058		266326-2	TAPPING SCREW 4X18	8	PC.
059		911233-1	PAN HEAD SCREW M5X20	4	PC.
060		136371-0	PIPE BRACKET ASSY	1	PC.
060	INC.		Item No. 63		
061		922202-7	HEX. SOCKET HEAD BOLT M5X8	1	PC.
062		922233-6	H.S.H.BOLT M5X20 WITH WR	1	PC.
063		263002-9	RUBBER PIN 4	1	PC.
064		127641-8	DAMPER SHAFT ASSEMBLY	1	PC.
064	INC.		Item No. 65-72		
065		327600-4	JOINT SLEEVE	1	PC.
066		256964-8	PIN 5	1	PC.

Item No	Type	Part No	Description	Qty	Unit
067		232625-4	TORSION SPRING 12	1	PC.
068		327601-2	SPINDLE HUB	1	PC.
069		211232-6	BALL BEARING 6002LLU	1	PC.
070		226997-7	HELICAL GEAR 33	1	PC.
071		253744-3	FLAT WASHER 12	1	PC.
072		211150-8	BALL BEARING 6901ZZ	1	PC.
073		183P84-0	HOUSING SET	1	SET
073	INC.	263005-3	RUBBER PIN 6	10	PC.
074		266459-3	TAPPING SCREW 5X25	4	PC.
075		136231-6	GEAR BOX ASS'Y	1	PC.
075	INC.		Item No. 76		
076		213961-7	O RING 22	1	PC.
077		510470-0	ROTOR ASS'Y	1	PC.
077	INC.		Item No. 78-80		
078		226996-9	HELICAL GEAR 16	1	PC.
079		210005-4	BALL BEARING 608DDW	1	PC.
080		210062-2	BALL BEARING 607ZZ	1	PC.
081		459764-7	BAFFLE PLATE	1	PC.
082		266326-2	TAPPING SCREW 4X18	2	PC.
083	1	629A12-6	* STATOR	1	PC.
083	2	629C15-2	* STATOR	1	PC.
084		459763-9	MOTOR HOUSING	1	PC.
087	2	620F58-5	CONTROLLER	1	PC.
088		644809-6	TERMINAL	2	PC.
089		811E38-8	DUA251 SERIAL NO. LABEL	1	PC.
091		266326-2	TAPPING SCREW 4X18	8	PC.
092		811E37-0	DUA251 NAME PLATE	1	PC.
093		412645-6	GUARD	1	PC.
094		266326-2	TAPPING SCREW 4X18	4	PC.
096		140V20-5	SHAFT C COMPLETE	1	PC.
096	INC.	162823-5	SPINDLE D COMPLETE	1	PC.
098		412631-7	LOCK RING	1	PC.
099		412632-5	LOCK SLEEVE	1	PC.
100		412630-9	LOCK SCREW	1	PC.
100	INC.	931202-6	HEX. NUT M5	2	PC.
101		922243-3	HEX. SOCKET HEAD BOLT M5X25	2	PC.
102		140V14-0	PIPE 38 COMPLETE B US	1	PC.
102	INC.	8016N4-7	CAUTION LABEL	1	PC.
103		412634-1	GRIP END 38	1	PC.

Item No	Type	Part No	Description	Qty	Unit
104		922243-3	HEX. SOCKET HEAD BOLT M5X25	1	PC.
105		232624-6	COMPRESSION SPRING 28	5	PC.
106		413312-6	DRIVE BUSH	8	PC.
107		211148-5	BALL BEARING 6001ZZ	4	PC.
108		412625-2	SLIDE BUSH	4	PC.
109		412633-3	PIPE SLEEVE 24	2	PC.
110		327599-3	SHOULDER PIN 6	1	PC.
111		412629-4	PIPE JOINT	1	PC.
112		922243-3	HEX. SOCKET HEAD BOLT M5X25	3	PC.
113		140V18-2	PIPE 24 COMPLETE	1	PC.
115		183R91-5	GEAR CASE COVER SET	1	SET
117		136393-0	SHAFT ASS'Y	1	PC.
117	INC.		Item No. 125		
118		412627-8	BEARING HOUSING B	2	PC.
119		327609-6	PIPE 28	1	PC.
120		412625-2	SLIDE BUSH	1	PC.
121		211148-5	BALL BEARING 6001ZZ	1	PC.
122		412624-4	BEARING HOUSING A	2	PC.
123		412623-6	LINER 15	1	PC.
124		412626-0	PIPE SLEEVE 28	2	PC.
125		136393-0	SHAFT ASS'Y	1	PC.
125	INC.		Item No. 117		
126		265954-0	TAPPING SCREW BIND PT3X8	1	PC.
127		412625-2	SLIDE BUSH	1	PC.
128		211148-5	BALL BEARING 6001ZZ	1	PC.
129		620K74-7	* CONTROLLER B	1	PC.
130		638A33-7	* LEAD UNIT	1	PC.
131		638A33-7	* PH SCREW M2X6	6	PC.
A01	1	161846-0	10" SPROCKET GUIDE BAR 3/8" 43G	1	PC.
A01	2	191G14-3	10" SPROCKET GUIDE BAR 3/8" 43G	1	PC.
A02		458501-6	GUIDE BAR CASE	1	PC.
A03	1	199075-5	3/8" CHAIN 43G 10"	1	PC.
A03	2	191H00-0	3/8" CHAIN 43G 10"	1	PC.
A04		782023-7	WRENCH 13-16	1	PC.
A06	1	182229-1	CHAIN OIL 100CC	1	PC.
A06	2	199897-3	CHAIN OIL 100CC	1	PC.
A07		783202-0	HEX. WRENCH 4	1	PC.
A08		422596-5	CAP 28	2	PC.
A09		424434-7	CAP 24	1	PC.

Item No	Type	Part No	Description	Qty	Unit
A10		191K37-5	SHOULDER BAND ASSEMBLY	1	PC.
A12		450128-8	BATTERY COVER	1	PC.
A13		-----	BATTERY CHARGER	1	PC.
A14		-----	18V LI-ION BATTERY	1	PC.
F08		1910J6-0	ANGLE CHANGE ADAPTOR ATTACHMENT	6	PC.


SERVICE CHANGES: DUA251

1. Changes on Oil Tank Assy and Gear Case Assy (T/I#DN700)

Item No.	Description	Type 1	Type 2
24	OIL TANK ASSEMBLY	136372-8	137016-3
26	GEAR CASE ASSEMBLY	136301-1	137017-1

Above parts are completely interchangeable as a set.

Shapes of Oil tank assembly/Gear case assembly have been changed.



2. Changes on Stator (T/I#DM424)

Item No.	Description	Type 1	Type 2
83	STATR	629A12-6	629C15-2
129	CONTROLLER B	-----	620K74-7
130	LEAD UNIT	-----	638A33-7
131	PAN HEAD SCREW M2X6	-----	652119-7

Above parts are completely interchangeable as a set.

See T/I#DM424 for wiring