



Item No.	Type	Sub	Part No.	Description	Qty	Unit
001			AL00000106	PAN HEAD SCREW M5X50	1	PC.
002			AL00000002	LEFT WHEEL COVER	1	PC.
003			AL00000003	HEX NUT M12 LH	1	PC.
004			AL00000004	OUTER FLANGE 60	1	PC.
005			AL00000005	INNER FLANGE 60	1	PC.
006	1		AL00000110	SCREW M5X10	3	PC.
	2		AL00000304	PAN HEAD SCREW M5X10 WITH W	3	PC.
007			AL00000006	LEFT WHEEL GUARD (INNER)	1	PC.
008			AL00000114	PAN HEAD SCREW M4X6	4	PC.
009			AL00000007	CORD CLAMP	1	PC.
010			AL00000132	SPRING WASHER 5	1	PC.
011			AL00000121	HEX NUT M5	1	PC.
012			AL00000008	LAMP COVER BASE	1	PC.
013			AL00000009	PLASTIC HEX NUT M10	1	PC.
014			AL00000102	BIND HEAD SCREW M4X6	2	PC.
015			AL00000010	CORD CLAMP BASE	1	PC.
016			AL00000104	PAN HEAD SCREW M4X10	2	PC.
017			AL00000105	PAN HEAD SCREW M4X30	2	PC.
018			AL00000011	LAMP COVER ASSY	1	PC.
019	2		AL00000303	LAMP SOCKET S-25 US	1	PC.
020			AL00000013	BULB S-25 12V 10W	1	PC.
021			AL00000014	KNOB BOLT M4X12	1	PC.
022	1		AL00000116	HEX BOLT M6X30	1	PC.
	2		AL00000119	HEX BOLT M6X30	1	PC.
023			AL00000127	FLAT WASHER 6	1	PC.
024			AL00000015	EYE SHIELD MOUNTING ARM L	1	PC.
025			AL00000016	EYE SHIELD L ASSY	1	PC.
026			AL00000121	HEX NUT M5	1	PC.
027			AL00000132	SPRING WASHER 5	1	PC.
028	1		AL00000115	HEX BOLT M5X10	1	PC.
	2		AL00000252	HEX BOLT M5X10 WITH WR	1	PC.
030			AL00000017	LEFT SPARK SHIELD	1	PC.
031			AL00000018	LEFT WORK REST	1	PC.
032			AL00000128	FLAT WASHER 8	2	PC.
033			AL00000132	SPRING WASHER 5	1	PC.
034			AL00000121	HEX NUT M5	1	PC.
035			AL00000118	HEX BOLT M8X10	2	PC.
036			AL00000113	PAN HEAD SCREW M5X135	4	PC.
037			AL00000126	FLAT WASHER 5	4	PC.
038			AL00000019	HOUSING R	1	PC.
039			AL00000100	BALL BEARING 6202	1	PC.
040			AL00000135	SPRING PIN 3X8	2	PC.
041			AL00000232	ROTOR	1	PC.
042			AL00000231	STATOR 120-127V 60HZ	1	PC.
043			AL00000022	GROMMET	1	PC.
044			AL00000023	HOUSING CENTER	1	PC.
045			AL00000108	PAN HEAD SCREW M4X8	4	PC.
046			AL00000024	CORD CLIP PLATE (3 HOLES)	1	PC.
047			AL00000103	PAN HEAD SCREW M4X8	2	PC.
048			AL00000170	POWER SUPPLY CORD NEMA 3P	1	PC.
051			AL00000026	GROMMET WITH STRAIN RELIEF	3	PC.
052			AL00000100	BALL BEARING 6202	1	PC.
053			AL00000027	WAVE SPRING WASHER 27.5	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
054			AL00000028	HOUSING L	1	PC.
055			AL00000132	SPRING WASHER 5	4	PC.
056			AL00000121	HEX NUT M5	4	PC.
057			AL00000122	HEX NUT M8	1	PC.
058	2		AL00000295	PAN HEAD SCREW M4X7 WITH WG	1	PC.
059			AL00000029	CAPACITOR SUPPORT	1	PC.
060			AL00000139	CAPACITOR 8 MICRO F/300V	1	PC.
061			AL00000131	SPRING WASHER 4	2	PC.
062			AL00000120	HEX NUT M4	4	PC.
063			AL00000131	SPRING WASHER 4	2	PC.
064			AL00000108	PAN HEAD SCREW M4X8	6	PC.
065			AL00000031	SWITCH BOARD	1	PC.
066			AL00000103	PAN HEAD SCREW M4X8	2	PC.
067			AL00000168	SWITCH WITH COVER	1	PC.
069			AL00000134	TOOTHED LOCK WASHER 4	1	PC.
070	2		AL00000295	PAN HEAD SCREW M4X7 WITH WG	1	PC.
071			AL00000106	PAN HEAD SCREW M5X50	1	PC.
072			AL00000034	RIGHT WHEEL COVER	1	PC.
073			AL00000035	HEX NUT M12	1	PC.
074			AL00000004	OUTER FLANGE 60	1	PC.
075			AL00000013	BULB S-25 12V 10W	1	PC.
076			AL00000011	LAMP COVER ASSY	1	PC.
077			AL00000105	PAN HEAD SCREW M4X30	2	PC.
078			AL00000104	PAN HEAD SCREW M4X10	2	PC.
079			AL00000010	CORD CLAMP BASE	1	PC.
080			AL00000102	BIND HEAD SCREW M4X6	2	PC.
081			AL00000009	PLASTIC HEX NUT M10	1	PC.
082			AL00000008	LAMP COVER BASE	1	PC.
083			AL00000012	LAMP SOCKET S-25	1	PC.
084			AL00000007	CORD CLAMP	1	PC.
085			AL00000114	PAN HEAD SCREW M4X6	4	PC.
086			AL00000036	RIGHT SPARK SHIELD	1	PC.
088	1		AL00000115	HEX BOLT M5X10	1	PC.
	2		AL00000252	HEX BOLT M5X10 WITH WR	1	PC.
089			AL00000037	EYE SHIELD WITH MAGNIFYER	1	PC.
090			AL00000038	EYE SHIELD MOUNTING ARM R	1	PC.
091			AL00000014	KNOB BOLT M4X12	1	PC.
092			AL00000039	COOLANT TRAY	1	PC.
093			AL00000040	UNDER COVER	1	PC.
094			AL00000041	PUBBER FOOT	4	PC.
095			AL00000129	FLAT WASHER 4 (L) - removed	4	PC.
096	1		AL00000109	PAN HEAD SCREW M4X16 WITH R	4	PC.
	2		AL00000305	PAN HEAD SCREW M4X16 WITH R	4	PC.
097	1		AL00000116	HEX BOLT M6X30	1	PC.
	2		AL00000119	HEX BOLT M6X30	1	PC.
098			AL00000127	FLAT WASHER 6	1	PC.
099			AL00000121	HEX NUT M5	1	PC.
100			AL00000132	SPRING WASHER 5	1	PC.
101			AL00000121	HEX NUT M5	1	PC.
102			AL00000132	SPRING WASHER 5	1	PC.
103			AL00000005	INNER FLANGE 60	1	PC.
104	1		AL00000110	SCREW M5X10	3	PC.
	2		AL00000304	PAN HEAD SCREW M5X10 WITH W	3	PC.
105			AL00000042	RIGHT WHEEL GUARD (INNER)	1	PC.
106			AL00000043	RIGHT WORK REST	1	PC.

Item No.	Type	Sub	Part No.	Description	Qty	Unit
107			AL00000132	SPRING WASHER 5	1	PC.
108			AL00000121	HEX NUT M5	1	PC.
109			AL00000128	FLAT WASHER 8	2	PC.
110			AL00000118	HEX BOLT M8X10	2	PC.
111			AL00000143	PAN HEAD SCREW M5X46	2	PC.
113			AL00000133	SPRING WASHER 6	1	PC.
118			AL00000133	SPRING WASHER 6	1	PC.
120			AL00000143	PAN HEAD SCREW M5X46	2	PC.

ACCESSORIES

- Visit www.makita.ca for more accessories information -

A01			AL00000044	WRENCH 8-19	1	PC.
A02			AL00000045	WRENCH 10-13	1	PC.
A03			B-51926	6" GRINDING WHEEL WA 60 150X16X12.7	1	PC.
A04			B-51932	6" GRINDING WHEEL GC 120 150X16X12.7	1	PC.
A05			AL00000147	SAFETY GOGGLE	1	PC.
A06			B-51904	6" GRINDING WHEEL A36M	1	PC.
A07			B-51910	6" GRINDING WHEEL A60M	1	PC.
A08			A-47547	WHEEL TOOL	1	PC.