



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		422613-1	DUST COVER	1	PC.
002		191N94-1	HOUSING SET	1	SET
002	INC.	8028C3-7	INDICATION LABEL	1	PC.
002	INC.	263002-9	RUBBER PIN 4	2	PC.
002	2 INC.	8028C2-9	CAUTION LABEL	1	PC.
003		266130-9	TAPPING SCREW BIND PT 3X16	7	PC.
004		232659-7	LEAF SPRING	1	PC.
005		127720-2	SPEED CHANGE LEVER ASSEMBLY	1	PC.
005	INC.	232636-9	COMPRESSION SPRING 3	2	PC.
006		413228-5	HEAD COVER	1	PC.
007		413229-3	+ROUND HEAD SCREW M8X10	2	PC.
008	2	122D56-8	GEAR ASSEMBLY	1	PC.
009		266130-9	TAPPING SCREW BIND PT 3X16	4	PC.
010		619663-7	ROTOR	1	PC.
011		629A37-0	STATOR	1	PC.
012		266490-9	TAPPING SCREW PT 2X6	3	PC.
013		620D23-2	CONTROLLER	1	PC.
014		412697-7	LOCK OFF BUTTON	1	PC.
015		651489-1	SWITCH C3JW-4B-L6	1	PC.
016		644813-5	TERMINAL	1	PC.
017		858C13-1	PV301D SERIAL NO. LABEL	1	PC.
018		422613-1	DUST COVER	1	PC.
020		858C06-8	PV301D NAME PLATE	1	PC.
A01		140X75-2	GRIP 30 COMPLETE	1	PC.
A02		191N90-9	SPONGE PAD 80 SET (DIA. 75MM)	1	PC.
A03		191N91-7	SPONGE PAD 80 SET (DIA. 75MM)	1	PC.
A04		191N92-5	WOOL PAD 80 SET (DIA. 75MM)	1	PC.
A05		743124-6	ROLOC PAD 50	1	PC.
A06		743125-4	H/L MAGIC PAD 80 (DIA. 75MM)	1	PC.
A07		743126-2	ADAPTER	1	PC.
A08		DC10SB	RAPID CHARGER DC18SB	1	PC.
A09		-----	12V CXT SLIDE TYPE LI-ION BATTERY	1	PC.
A10		456128-6	12V CXT SLIDE LI-ION BATTERY COVER	1	PC.
A22		781006-4	WRENCH 13	1	PC.