





PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
002		303209-000	HOSE	1	PC.
003		303071-001	KNOB	1	PC.
005		021200-001	SPRING WASHER	1	PC.
006		021101-027	FLAT WASHER	1	PC.
007		020613-001	HEX.SOCKET BOLT	1	PC.
008		270310-000	BLADE SUPPORTER & GUARD	1	PC.
009		021104-023	FLAT WASHER	1	PC.
010		020601-003	HEX.SOCKET BOLT	1	PC.
011		290081-000	DUST BLOWER	1	PC.
012		021104-023	FLAT WASHER	1	PC.
013		020601-003	HEX.SOCKET BOLT	1	PC.
015		290079-000	SUPPORT ROD	1	PC.
016		026104-001	PIN SPRINGR	1	PC.
017		020601-003	HEX.SOCKET BOLT	1	PC.
018		021104-023	FLAT WASHER	1	PC.
019		270309-000	HOLD DOWN FOOT	1	PC.
020		020505-003	SET SCREW	1	PC.
021		225070-000	HOLD DOWN BLOCK	1	PC.
022	1	303204-000	MOTOR REAR COVER	1	PC.
022	1	INC. 303205-000	BRUSH HOLDER	2	PC.
022	2	303204-003	MOTOR REAR COVER	1	PC.
022	2	INC. 303205-001	BRUSH HOLDER	2	PC.
023		050007-000	BEARING	1	PC.
024		900312-000	FIELD ASS'Y WITH MOTOR HOUSING	1	PC.
027	1	375008-000	CARBON BRUSH 2PC/SET	2	SET
027	2	375009-000	CARBON BRUSH 2PC/SET	2	SET
027	3	375009-001	CARBON BRUSH 2PC/SET	2	SET
028	1	303000-000	BRUSH HOLDER CAP	2	PC.
028	2	303000-001	BRUSH HOLDER CAP	2	PC.
029		224053-000	TABLE	1	PC.
030		021402-001	WAVE WASHER	1	PC.
031		020614-001	SOCKET HEAD SCREW	1	PC.
032		270311-000	TILT BRACKET	1	PC.
033		021101-025	FLAT WASHER	1	PC.
035		900403-000	LOCK HANDLE ASS'Y	1	PC.
035	INC.	132060-000	SHAFT	1	PC.
035	INC.	303215-000	BAVEL LEVER	1	PC.
035	INC.	029143-001	COMPRESSION SPRING	1	PC.
035	INC.	132057-000	BOLT	1	PC.
038		080171-000	POWER CORD	1	PC.
039		020219-001	SCREW	3	PC.

Item No	Type	Part No	Description	Qty	Unit
040	1	162008-002	ARMATURE ASSY WITH BEARINGS	1	PC.
040	1	INC. 0	Item No. 23,41		
040	2	880084-000	ARMATURE ASS'Y WITH BEARINGS	1	PC.
040	2	INC. 0	Item No. 23,41		
041		050015-100	BEARING	1	PC.
042		225083-000	MOTOR FRONT COVER	1	PC.
043		240051-000	BASE	1	PC.
044		020103-015	SCREW	1	PC.
045		913002-000	BUSHING	1	PC.
046		913002-000	BUSHING	1	PC.
047		020103-015	SCREW	1	PC.
048		270248-000	BUSHING SET COVER	1	PC.
049	1	302043-000	* SWITCH CASE	1	PC.
049	2	302043-003	* SWITCH CASE	1	PC.
050		020103-015	SCREW	1	PC.
053	1	863301-003	* INDICATION LABEL	1	PC.
053	2	863305-007	* INDICATION LABEL	1	PC.
053	3	863305-006	* INDICATION LABEL	1	PC.
054		022804-000	NUT	1	PC.
055		290080-000	* LOCK POST - No longer available individually	1	PC.
056		020228-001	SCREW	1	PC.
057	1	303259-000	* SWITCH COVER, BLK, PLASTIC	1	PC.
057	2	303259-001	* SWITCH COVER, BLK, PLASTIC	1	PC.
058		021308-001	* EXT.TOOTH WASHER - No longer available individually	1	PC.
059		020103-015	SCREW	1	PC.
060	1	022301-001	NUT	1	PC.
060	2	022804-000	NUT	1	PC.
061		020103-015	SCREW	1	PC.
062		020103-015	SCREW	1	PC.
063		020228-001	SCREW	1	PC.
065		303207-000	CONTROL KNOB	1	PC.
067		370021-000	* SWITCH,WASHER & NUT	1	PC.
068		020726-001	PAN HEAD SCREW	1	PC.
069	1	270249-000	POINTER F/ BASE	1	PC.
069	2	303242-000	POINTER F/ BASE	1	PC.
071		021306-001	LOCK WASHER	1	PC.
073		020103-015	SCREW	2	PC.
074		021306-001	LOCK WASHER	1	PC.
075		020720-003	SCREW & WASHER	2	PC.
076		020720-003	SCREW & WASHER	2	PC.
077		240042-000	COUNTERWEIGHT	1	PC.
078		060047-000	SPACER	1	PC.
079		020508-001	SET SCREW	1	PC.

Item No	Type	Part No	Description	Qty	Unit
080		020723-007	SCREW & WASHER	3	PC.
081		270308-000	PLATE COVER	1	PC.
082		020106-013	SCREW	1	PC.
083		024201-001	PULL NAIL	1	PC.
084		024201-001	PULL NAIL	1	PC.
085		303202-000	BLADE STORAGE CASE	1	PC.
086		020106-013	SCREW	1	PC.
087	1	020200-001	SCREW	2	PC.
087	2	020200-017	SCREW	2	PC.
088	1	020200-001	SCREW	2	PC.
088	2	020200-017	SCREW	2	PC.
089	1	303203-000	BOARD COVER	1	PC.
089	2	900782-004	BOARD COVER ASSY (120V)	1	PC.
090		900625-002	* CONTROL BOARD ASS'Y (120V)	1	PC.
091	1	225112-000	ARM COVER(LEFT)	1	PC.
091	2	900570-000	ARM COVER ASSY (LEFT & RIGHT)	1	PC.
092		026202-007	PIN	1	PC.
093		020702-001	COVER SET SCREW	1	PC.
094		020702-001	COVER SET SCREW	1	PC.
095		020702-001	COVER SET SCREW	1	PC.
096		020702-001	COVER SET SCREW	1	PC.
097		020702-001	COVER SET SCREW	1	PC.
098	1	225111-000	ARM COVER(RIGHT)	1	PC.
098	2	900570-000	ARM COVER ASSY (LEFT & RIGHT)	1	PC.
099		330026-000	AIR DIAPHRAGM	1	PC.
100		020702-001	COVER SET SCREW	1	PC.
101		020702-001	COVER SET SCREW	1	PC.
102		020702-001	COVER SET SCREW	1	PC.
103		225069-000	BLADE TENSION LEVER	1	PC.
104		026104-009	PIN	1	PC.
105		290078-000	TENSION ADJUSTING BOLT	1	PC.
106		021100-011	FLAT WASHER	1	PC.
108		029141-001	SPRING	1	PC.
109		026103-015	ROLL PIN	1	PC.
110		020608-003	HEX.SOCKET BOLT	1	PC.
111		250006-000	UPPER BLADE NUT	1	PC.
112		029144-001	COMPRESSION SPRING	1	PC.
113		250005-000	UPPER BLADE HOLDER	1	PC.
114		250004-000	LOWER BLADE NUT	1	PC.
115		026103-015	ROLL PIN	1	PC.
116		029144-001	COMPRESSION SPRING	1	PC.
117		250003-000	LOWER BLADE HOLDER	1	PC.
118		026107-001	PIN	1	PC.

Item No	Type	Part No	Description	Qty	Unit
119		020608-003	HEX.SOCKET BOLT	1	PC.
120		026107-001	PIN	1	PC.
121		225073-000	BLADE SUPPORT	1	PC.
122		026102-007	PIN	1	PC.
123		020600-001	HEX. SOCKET BOLT	1	PC.
124		026103-015	ROLL PIN	1	PC.
125		060052-000	SPACER	1	PC.
126		303201-000	ARM LINK	1	PC.
127		050012-000	BEARING	1	PC.
128		270252-000	BEARING FENCE	1	PC.
129		020200-015	SCREW	1	PC.
130		022101-001	NUT	1	PC.
131		021101-027	FLAT WASHER	1	PC.
132		050012-000	BEARING	1	PC.
133		224042-000	LOWER ARM	1	PC.
134		053014-000	BEARING FLANGE	1	PC.
135		028935-001	SET SCREW	1	PC.
136		021202-003	SPRING WASHER	1	PC.
137		022101-001	NUT	1	PC.
138		290077-000	ARM PIN	1	PC.
139		053014-000	BEARING FLANGE	1	PC.
140		053014-000	BEARING FLANGE	1	PC.
141		270251-000	CONNECTOR	1	PC.
142		028935-001	SET SCREW	1	PC.
143		021202-003	SPRING WASHER	1	PC.
144		022101-001	NUT	1	PC.
145		224041-000	UPPER ARM	1	PC.
146		290077-000	ARM PIN	1	PC.
147		053014-000	BEARING FLANGE	1	PC.
148		914019-000	SPONGE	1	PC.
149		020127-003	SCREW	2	PC.
150		090042-000	* SWITCH	1	PC.
151		020216-005	* SCREW	2	PC.
152		990026-000	MOTOR	1	PC.
152	1	INC.	Item No. 22-24,27,28,40-42,149		
152	2	INC.	Item No. 22-24,27,28,40-42,149, 153		
153		303205-001	BRUSH HOLDER	2	PC.
154		021410-001	WASHER F/ARMATURE (Added)	1	PC.
A01		351011-000	SCROLL SAW BLADE	1	PC.
A02		040026-001	BLADE CHANGING ROD	1	PC.
A03		040005-003	HEX WRENCH "L" M3	1	PC.
A04		040006-001	HEX WRENCH "L" M4	1	PC.

SERVICE CHANGES: SJ401

1. Changes on Control Board Assy, Switch, etc.

Item No.	Description	Type 1	Type 2
151	SCREW (Added)	----	020216-005
90	CONTROL BOARD ASS'Y	900313-003	900625-002
67	SWITCH,WASHER,NUT	090033-001	370021-000
57	SWITCH COVER	303259-000	303259-001
53	STICKER F/ SWITCH COVER	863301-003	863305-007
55	LOCK POST	290080-000	----
49	SWITCH CASE	302043-000	302043-003
58	EXT.TOOTH WASHER	021308-001	----
150	SWITCH	----	090042-000