





## PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		183S36-9	GRIP SET	1	SET
004		233101-1	COMPRESSION SPRING 4	1	PC.
005		459759-0	LOCK OFF LEVER	1	PC.
006		233622-3	TORSION SPRING 12	1	PC.
007		459758-2	SWITCH LEVER	1	PC.
008		651492-2	SWITCH C3JR-1A-PAXD3	1	PC.
009		141B32-1	INDICATION CIRCUIT COMPLETE E	1	PC.
010		140W06-5	SWITCH CIRCUIT COMPLETE G	1	PC.
010	INC.	819J26-9	SWITCH LABEL	1	PC.
011		922233-6	H.S.H.BOLT M5X20 WITH WR	1	PC.
013		266326-2	TAPPING SCREW 4X18	6	PC.
014		699159-4	POWER SUPPLY CORD UNIT	1	PC.
015		183S34-3	HOUSING SET	1	SET
015	INC.	263005-3	RUBBER PIN 6	2	PC.
017		346248-3	CLAMP 24	1	PC.
018		266326-2	TAPPING SCREW 4X18	1	PC.
019		8012U4-2	XGT LOGO LABEL	1	PC.
021	2	620J68-6	* CONTROLLER	1	PC.
022		632P49-4	TERMINAL UNIT	1	PC.
024		811A61-9	UR003G NAME PLATE	1	PC.
025		266326-2	TAPPING SCREW 4X18	5	PC.
026		422230-7	CAP	1	PC.
027		266420-0	TAPPING SCREW 5X20	2	PC.
028		347752-5	BATTERY GUARD	1	PC.
029		347114-7	LOWER CLAMP 35	1	PC.
030		347113-9	UPPER CLAMP 35	1	PC.
031		457267-5	LOOP HANDLE	1	PC.
031	INC.	263005-3	RUBBER PIN 6	1	PC.
032		911233-1	PAN HEAD SCREW M5X20	4	PC.
033		413335-4	TOP COVER	1	PC.
034		210062-2	BALL BEARING 607ZZ	1	PC.
035	2	520136-4	* STATOR ASS'Y	1	PC.
035	2	INC.	* Item No. 34,57		
036		619462-7	ROTOR	1	PC.
037		911128-8	P.H.SCREW M4X16 WITH WR	2	PC.
038		455628-3	INNER COVER	1	PC.
039		620E48-2	CONTROLLER B	1	PC.
040		911128-8	P.H.SCREW M4X16 WITH WR	1	PC.

Item No	Type	Part No	Description	Qty	Unit
041		687042-7	STRAIN RELIEF	1	PC.
042		922223-9	H.S.H.BOLT M5X16 WITH WR	2	PC.
043		922241-7	HEX. SOCKET HEAD BOLT M5X25	1	PC.
044		141A05-8	MOTOR HOUSING COMPLETE	1	PC.
045		211131-2	BALL BEARING 6001DDW	1	PC.
046		962106-1	RETAINING RING R-28	1	PC.
047		140L84-9	RECEIVE WASHER COMPLETE G	1	PC.
048		346084-7	CLAMP WASHER	1	PC.
056		141B09-6	PIPE COMPLETE L	1	PC.
056	INC.	819312-8	MAKITA LOGO LABEL	1	PC.
056	INC.	8001T8-8	CAUTION LABEL	1	PC.
057		213325-5	O RING 19	1	PC.
058		168526-9	CUP	1	PC.
059		264025-0	HEX. NUT M10-17	1	PC.
060		451601-1	SPACER 24	1	PC.
061		457269-1	PIPE HOLDER 24	1	PC.
062		922244-1	H.S.H.BOLT M5X25 WITH WG	1	PC.
063		424942-8	DAMPER	1	PC.
064		922234-4	H.S.H.BOLT M5X20 WITH WG	2	PC.
065		144315-6	BARRIER COMPLETE	1	PC.
065	INC.		Item No. 66		
066		911128-8	P.H.SCREW M4X16 WITH WR	1	PC.
067		266579-3	HEX SOCKET HEAD BOLT M6X30	2	PC.
068		253428-3	SPRING WASHER 6	2	PC.
069		346073-2	PROTECTOR CLAMP	1	PC.
070		413143-3	WASHER	2	PC.
071		459504-3	PROTECTOR N 380	1	PC.
072		346855-2	CUTTER	1	PC.
073		266326-2	TAPPING SCREW 4X18	2	PC.
074		422727-6	RUBBER CAP	1	PC.
075		811A67-7	UR003G SERIAL NO. LABEL	1	PC.
A01		127508-0	SHOULDER HARNESS	1	PC.
A02	2	191R00-0	BUMP&FEED 4" TRIMMER HEAD ASSEMBLY M10X1.25LH	1	PC.
A03		783013-3	BOX DRIVER 16-17	1	PC.
A04		783202-0	HEX. WRENCH 4	1	PC.
A05		831304-7	ACCESSORY BAG	1	PC.
A10		783217-7	HEX. WRENCH 5	1	PC.
A11		412393-7	BATTERY COVER F/ XGT LI-ION	1	PC.
A12		BL4040	40V MAX LI-ION BATTERY BL4040	1	PC.

Item No	Type	Part No	Description	Qty	Unit
A13		BL4025	40V MAX LI-ION BATTERY BL4025	1	PC.
A14		DC40RA	FAST CHARGER DC40RA	1	PC.
A15	1	196324-1	BUMP&FEED 4" TRIMMER HEAD ASSEMBLY M10X1.25LH UN	1	PC.
A15	2	T-03676	MEDIUM SWIFT LOAD (LH)	1	PC.
A16	1	191D89-4	BUMP&FEED 4" TRIMMER HEAD ASSEMBLY M10X1.25LH	1	PC.
A16	2	191R00-0	BUMP&FEED 4" TRIMMER HEAD ASSEMBLY M10X1.25LH	1	PC.
A17		198892-0	BUMP&FEED 4" 95-M10L TRIMMER HEAD ASSEMBLY M10X1.25LH	1	PC.

## SERVICE CHANGES: UR003G

### 1. Changes on Controller and Stator Assembly (T/I#DC879)

Item No.	Description	Type 1	Type 2
021	CONTROLLER	620E70-9	620J68-6
035	STATOR ASSEMBLY	529146-8	520136-4

Above parts are completely interchangeable as a set.