



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		122D73-8	GEAR CASE ASSEMBLY R	1	PC.
001	INC.		Item No. 2,5,7-9,13,16		
002		265590-2	+HEX.BOLT M8X10 WITH R	1	PC.
003		210030-5	BALL BEARING 627ZZ	1	PC.
004		227A47-7	ZEROL BEVEL GEAR 21	1	PC.
005		136860-5	CUTTER SHAFT US ASSEMBLY	1	PC.
005	INC.		Item No. 3,4,6		
006		211228-7	BALL BEARING 6202DDW	1	PC.
007		259069-3	RETAINING RING (INT) R-35	1	PC.
008		327B76-7	RECEIVE WASHER R	1	PC.
009		252236-9	HEX. LOCK NUT M10-17	1	PC.
013		136861-3	SPIRAL BEVEL GEAR ASSEMBLY	1	PC.
013	INC.		Item No. 14,15		
014		210157-1	BALL BEARING 609ZZ	2	PC.
015		259071-6	RETAINING RING (EXT) S-9	1	PC.
016		259072-4	RETAINING RING (INT)R-24	1	PC.
018		922216-6	H.S.H.BOLT M5X14 WITH W	1	PC.
019		922353-6	HEX.SOCKET HEAD BOLT M6X30	1	PC.
020		327056-1	SHAFT	1	PC.
021		266280-0	HEX. SOCKET HEAD BOLT M6X25	2	PC.
022		347B13-5	PROTECTOR CLAMP 25G	1	PC.
023		922216-6	H.S.H.BOLT M5X14 WITH W	1	PC.
024		413N78-2	PROTECTOR 450	1	PC.
025		141P52-9	SHAFT PIPE COMPLETE G	1	PC.
025	INC.	819W06-3	CAUTION LABEL	1	PC.
025	INC.	819312-8	MAKITA LOGO LABEL	1	PC.
025	INC.	8076F1-5	CAUTION LABEL	1	PC.
025	INC.	8064J5-0	CAUTION LABEL	1	PC.
026		457267-5	LOOP HANDLE	1	PC.
027		922234-4	H.S.H.BOLT M5X20 WITH WG	2	PC.
028		347113-9	UPPER CLAMP 35	1	PC.
029		413P01-9	PIPE HOLDER 25	1	PC.
030		266326-2	TAPPING SCREW 4X18	1	PC.
031		347114-7	LOWER CLAMP 35	1	PC.
032		424942-8	DAMPER	1	PC.
033		413P05-1	SPACER 25 - removed	1	PC.
034		266326-2	TAPPING SCREW 4X18	6	PC.
035		183X43-2	GRIP SET	1	SET

Item No	Type	Part No	Description	Qty	Unit
035	INC.	931202-6	HEX. NUT M5	1	PC.
036		141N51-9	INDICATION CIRCUIT COMPLETE E	1	PC.
037		141N47-0	SWITCH CIRCUIT COMPLETE G	1	PC.
037	INC.	8064D9-0	SWITCH LABEL	1	PC.
038		413N93-6	SWITCH LEVER	1	PC.
039		632U35-5	SWITCH UNIT	1	PC.
040		233622-3	TORSION SPRING 12	1	PC.
041		413P00-1	LOCK OFF LEVER	1	PC.
042		233101-1	COMPRESSION SPRING 4	1	PC.
044		651492-2	SWITCH C3JR-1A-PAXD3	1	PC.
045		922244-1	H.S.H.BOLT M5X25 WITH WG	1	PC.
046		632U36-3	SWITCH UNIT	1	PC.
047		922233-6	H.S.H.BOLT M5X20 WITH WR	1	PC.
048		413N94-4	CONTROL LEVER	1	PC.
049		413P03-5	GUARD	1	PC.
050		183X40-8	HOUSING SET	1	SET
050	INC.	263005-3	RUBBER PIN 6	2	PC.
050	INC.	8025F3-0	XGT LOGO LABEL	1	PC.
051		266420-0	TAPPING SCREW 5X20	4	PC.
052		136862-1	PIPE BRACKET ASS'Y	1	PC.
052	INC.	263002-9	RUBBER PIN 4	1	PC.
053		266326-2	TAPPING SCREW 4X18	1	PC.
054		413N95-2	LINK	1	PC.
055		213154-6	O RING 14	1	PC.
056		253798-0	FLAT WASHER 13	1	PC.
057		922211-6	H.S.H.BOLT M5X12 WITH W	1	PC.
058		922353-6	HEX.SOCKET HEAD BOLT M6X30	1	PC.
059		8585W2-9	UR014G NAME PLATE	1	PC.
060		8585W9-5	UR014G SERIAL NO. LABEL	1	PC.
061		210244-6	BALL BEARING 6001ZZ	1	PC.
063		210062-2	BALL BEARING 607ZZ	1	PC.
064		510551-0	ROTOR ASS'Y	1	PC.
064	INC.		Item No. 61,63		
065		266326-2	TAPPING SCREW 4X18	2	PC.
066		413N96-0	BAFFLE PLATE	1	PC.
067		629B96-0	STATOR	1	PC.
068		413N72-4	MOTOR HOUSING	1	PC.
069		632T07-4	TERMINAL UNIT	1	PC.
070		620L82-4	CONTROLLER	1	PC.

Item No	Type	Part No	Description	Qty	Unit
071		652031-1	PAN HEAD SCREW M3X6	2	PC.
072		266420-0	TAPPING SCREW 5X20	2	PC.
073		422230-7	CAP	1	PC.
074		327B36-9	BATTERY GUARD	1	PC.
077		266326-2	TAPPING SCREW 4X18	7	PC.
078		652069-6	FLAT HEAD SCREW M3X6	3	PC.
079		632R96-7	SENSOR UNIT	1	PC.
080	1	652093-9	PAN HEAD SCREW M2X5	3	PC.
080	2	652119-7	PAN HEAD SCREW M2X6	3	PC.
081		327742-4	D RING 20	1	PC.
082		347783-4	RING SUPPORT	1	PC.
083		266388-0	TAPPING SCREW 5X16	2	PC.
084		347B15-1	CUTTER	1	PC.
A01		127759-5	BAND ASSEMBLY L	1	PC.
A02		782210-8	SOCKET WRENCH 17	1	PC.
A03		783202-0	HEX. WRENCH 4	1	PC.
A04		783217-7	HEX. WRENCH 5	1	PC.
A05		1911Y3-7	BUMP&FEED 5 HEAD ASSY	1	PC.
A08		831304-7	ACCESSORY BAG	1	PC.
A10		-----	BATTERY CHARGER		
A11		-----	40V MAX LI-ION BATTERY		